

Ref: **3006.97000** ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS

Adattabile a – Suitable to : COS. IV S-WAY

1. Open the side window all the way.
2. Apply liquid soap or silicon spray to the edge of window deflector and side window gasket.
3. Peel off a little bit the tape protection film that you can see it when the window deflector is mounted to the vertical part of side window gasket.
4. Peel off completely the tape protection film.
5. Bend from rear of the deflector to mount it into horizontal part of window gasket. Use the two clips to hold deflector on its place as shown on picture 3.
6. Check that the window deflector is on its place.
7. Close and open side window 5 times to see that window deflector fits to the gasket. Leave the side window closed for at least 24h. After that side window should move freely.

